

Stihl 018 and MS 180 chainsaws



REF. NO.	DESCRIPTION	REPLACES STIHL	STENS NO.
1.	Air Filter	1130 124 0800	605-325
2.	a. Bosch Spark Plug	1110 400 7005	130-124
	b. NGK Spark Plug	0000 400 7000	130-898
3.	Spark Plug Boot	1128 405 1000	135-250
4.	Fuel Filter	0000 350 3500	610-170
5.	Starter Handle	1107 195 3400	140-129
6.	Starter Pawl	1125 195 7200	630-107
7.	Spring Clip	1118 195 3500	630-095
8.	Starter Spring	1129 190 0601	155-302
9.	Filler Cap	1130 350 0500	635-294
10.	Cylinder Assembly (38mm)	1130 020 1205	632-450
11.	Bar Nut	0000 955 0801	635-293
12.	Gasket Maker		751-708
13.	Clutch Assembly	1123 160 2001	646-170
14.	Sprocket (3/8 LP pitch, 6 teeth)	1123 640 2000	085-7177
15.	Sprocket Bearing	9512 933 2260	635-428
16.	a. Bar 12" (3/8 LP pitch, .043 gauge, 44 drive links)	3005 000 3905	079-2757
	b. Bar 14" (3/8 LP pitch, .043 gauge, 50 drive links)	3005 000 3909	079-2817
	c. Bar 16" (3/8 LP pitch, .043 gauge, 55 drive links)	3005 000 3913	079-2827
17.	a. Chain Loop Semi-Chisel (3/8 LP pitch, .043 gauge, 44 drive links)		094-5447
	b. Chain Loop Semi-Chisel (3/8 LP pitch, .043 gauge, 50 drive links)		094-5507
	c. Chain Loop Semi-Chisel (3/8 LP pitch, .043 gauge, 55 drive links)		094-5557
18.	Switch Shaft	1130 182 0900	635-012
19.	Torsion Spring	1117 182 4500	635-376
20.	T-Wrench	1129 890 3401	705-574
21.	T27 Power Bit 3 1/2"	0812 540 1111	705-190
22.	T27 Power Bit 6"	0812 540 1111	705-194
23.	Bar Guard (16")		705-224