

Stihl 021, 023, 025, MS210, MS230 and MS250 chainsaws



REF. NO.	DESCRIPTION	REPLACES STIHL	STENS NO.
1.	Air Filter	1123 120 1613	605-687
2.	a. Bosch Spark Plug (WSR6F)	1110 400 7005	130-124
	b. NGK Spark Plug (BPMR7A)	0000 400 7000	130-898
3.	Spark Plug Boot	1128 405 1000	135-250
4.	Ignition Coil	0000 400 1306	600-223
5.	Fuel Filter	0000 350 3500	610-170
6.	Primer Bulb	4130 350 6200	615-764
7.	Starter Handle	1107 195 3400	140-129
8.	Starter Pawl	1125 195 7200	630-107
9.	Spring Clip	1118 195 3500	630-095
10.	Starter Spring	1129 190 0601	155-302
11.	Filler Cap	0000 350 0520	610-296
12.	Oil Cap	0000 350 0510	610-300
13.	Bar Nut	0000 955 0801	635-293
14.	Gasket Maker		751-708
15.	Clutch Assembly	1123 160 2001	646-170
16.	a. Sprocket (3/8 LP pitch, 6 teeth)	1123 640 2000	085-7177
	b. Sprocket (.325 pitch, 7 teeth)	1123 640 2074	085-6217
17.	Sprocket Bearing	9512 933 2260	635-428
18.	a. Bar 12" (3/8 LP pitch, .050 gauge, 44 drive links)	3005 000 4805	077-1237
	b. Bar 16" (3/8 LP pitch, .050 gauge, 55 drive links)	3005 008 4813	077-1667
	c. Bar 16" (.325 pitch, .063 gauge, 62 drive links)		079-2857
19.	a. Chain Loop Semi-Chisel (3/8 LP pitch, .050 gauge, 44 drive links)		095-3447
	b. Chain Loop Semi-Chisel (3/8 LP pitch, .050 gauge, 55 drive links)		095-3557
	c. Chain Loop Semi-Chisel (.325 pitch, .063 gauge, 62 drive links)		096-5627
20.	Twist Lock	1123 141 2301	635-451
21.	Torsion Spring	1117 182 4500	635-376
22.	Trigger Interlock	1117 182 0805	635-523
23.	Throttle Trigger	1128 182 1005	635-410
24.	Pin	9371 470 2640	635-190
25.	T-Wrench	1129 890 3401	705-574
26.	T27 Power Bit 3 1/2"	0812 540 1111	705-190
27.	T27 Power Bit 6"	0812 540 1111	705-194
28.	Bar Guard (16")		705-224
29.	Maintenance Kit	1123 007 1800	605-108