

## Stihl MS 171, MS 181 and MS 211 chainsaws



REF. NO.	DESCRIPTION	REPLACES STIHL	STENS NO.
1.	Air Filter	1139 124 0800	605-350
2.	NGK Spark Plug (CMR6H)	0000 400 7011	130-355
3.	Spark Plug Boot	1128 405 1000	135-250
4.	Fuel Filter	0000 350 3500	610-170
5.	Primer Bulb	4130 350 6200	615-764
6.	Starter Handle	1107 195 3400	140-129
7.	Starter Pawl	1125 195 7200	630-107
8.	Spring Clip	1118 195 3500	630-095
9.	Starter Spring	1129 190 0601	155-302
10.	Bar Nut	0000 955 0801	635-293
11.	Gasket Maker		751-708
12.	Sprocket (3/8 LP pitch, 6 teeth)	1123 640 2000	085-7177
13.	Sprocket Bearing	9512 933 2260	635-428
14.	a. Bar 12" (3/8 LP pitch, .043 gauge, 44 drive links)	3005 000 3905	079-2757
	b. Bar 14" (3/8 LP pitch, .043 gauge, 50 drive links)	3005 000 3909	079-2817
	c. Bar 16" (3/8 LP pitch, .043 gauge, 55 drive links)	3005 000 3913	079-2827
15.	a. Chain Loop Semi-Chisel (3/8 LP pitch, .043 gauge, 44 drive links)		094-5447
	b. Chain Loop Semi-Chisel (3/8 LP pitch, .043 gauge, 50 drive links)		094-5507
	c. Chain Loop Semi-Chisel (3/8 LP pitch, .043 gauge, 55 drive links)		094-5557
16.	Switch Shaft	1130 182 0900	635-012
17.	Torsion Spring	1117 182 4500	635-376
18.	T-Wrench	1129 890 3401	705-574
19.	T27 Power Bit 3 1/2"	0812 540 1111	705-190
20.	T27 Power Bit 6"	0812 540 1111	705-194
21.	Bar Guard (16")		705-224